BRUSH REVETMENT

Stone or log framed wings to prevent scouring behind the structure 4' Rebar Sill logs trenched into streambank Streambank 2' Rebar Sill Logs

Note: Sill logs should be placed every 15-20 ft and attached to other trees using rebar if necessary Stone can be added on top of the brush/trees for structural integrity/ballast

