



FATHEAD MINNOW SPAWNING COVER
S T A N D A R D D R A W I N G



NOTES:
DENSITY: 6 COVERS PER ACRE.
POINT END OF BOARD TO DRIVE INTO EARTH.
DRIVE POINTED END 3" TO 6" INTO THE SHORE.
SPAWNING SEASON OCCURS FROM MAY TO JUNE.